

Robotics 311 : How to build robots and make them move

Prof. Elliott Rouse

GSI Yves Nazon MS

Fall 2022



ROB 311 – Lab 3

- Today:
 - Get your materials
 - Begin designing your plates / motor mount
 - We will walk around and help you
 - But dive in and starting playing with the provided files!

ROB 311 – Lab 3

- Please come pick up:

- 3x Pololu 37D gearmotors



- 3x motor couplers



- 4x acrylic sheets –
choose your colors!

Be sure to leave the protective film on—
this prevents damage to the surface
finish during cutting



- 2x strips of Velcro



- 6x omni wheel halves

These will be assembled into 3x omni
wheels



- 1x basketball



- 1x metric hex set +
1x imperial hex set



- 1x your RPi Pico
board



- 1x Blink M LED




- 2x wired mouse



ROB 311 – Lab 3


- First begin with:
 - Open `rob311-ball-bot.STEP`
 - This will let you look at our ball-bot design as a STEP file
 - Look at the different components and get a feel for how everything fits together
 - Once this has opened and you feel like you understand the different components you can move to designing the plates and motor mount
 - You're welcome to use our RPi isolator plate file / layout



`rob-311-ball-bot.STEP`
This file will allow you to view / manipulate the assembly, but it won't show the operations that created the parts

Lab 3 – Designing Ball-Bot Structures

- Over the next few labs, we will build the structures of the ball-bot
- We will begin with the motor mounts then move to the acrylic structures
- You will use these part files to have your designs made




Lab 3 – Designing Ball-Bot Structures (2D)


- Acrylic plates that need to be designed




RPi isolator plate



Middle plate





Top plate




Lab 3 – Designing Ball-Bot Structures (2D)

- Baseplate and template




Lab 3 – Designing Ball-Bot Structures (2D)



RPi
mounting
holes (x4)

RPi isolator plate



- The isolator plate holds the RPi Pico and IMU off the baseplate, mounted with rubber grommets
- Key idea is to reduce motor vibration impact on the IMU readings
- The RPi mounting holes will need to match the layout on the Raspberry Pi
- The isolator mounting holes can be anywhere, as long as they mount to holes on the baseplate
- The mounting holes for the RPi Pico are the same as the regular RPi

Lab 3 – Designing Ball-Bot Structures (3D)

- Provided part file with pre-made sketches:

